PI-WIFI

How to set up your Raspberry Pi's Wi-Fi adapter

Step 1:

Locate the icon titled WIFI Config.

Step 2:

Double click WIFI Config. Be patient as this will use resources in order to open a new window.

Step 3:

Near the bottom, right corner you should notice a button reading "Scan". Click "Scan" and a new window will pop up.

Step 4:

In the new window, you will see available Wi-Fi connections. Find your local connection and double click on its name, which you will find under the first column, entitled "SSID".

Step 5:

The fourth field should be called "PSK"; it is in this field that you will enter your Wi-Fi password. Proceed by clicking the second button located on the bottom called "Add".

Step 6:

Enjoy your Raspberry Pi's new wireless internet connection!